





NEW baby formula = NEW settings

4 New baby formula setup (manual operation)

(♦) @ http://www.agu-baby.co	om/en/catalog/milkmachine/milkformula-base/			C C Q rows		
select the required baby formula from list					[8] ≡	
1	My husband and I have been dreaming about us that there was no one on the planet happin with a joyful thrill about how we would care for	or than wel Every day we talks	d about our baby, w			
	Baby Formula	ML	°C	CON	READ MORE	
	Bebelak	90	37	3		
	Humana	120	40	4		
	HIPP	150	40	5	and the second	
	1-2 week	120	37	4	And a state of the	
	> 3-4 week	90	37	3	- Alexand	
	2 month	150	40	4		
	6000	press	ct ML	• (<u>a</u> o-)	or (+o)	
5) 703	(30 – 3 (30 – 3 press to sele (25 – 5	00 ml) ect °C	<u>(</u>	or (+o	

5 Preparing baby formula

V.

(2)

ON 4



Use ONLY room temperature boiled water. Do not add water warmer than 45 °C. Do not add unboiled water.